R-LinX
WiFi Button

Wireless **R-LinX** call button.
Simply press to send alerts and requests
to Hytera and Motorola radios.

Three stage escalation, multiple push
patterns, LED status ring and hundreds
of uses.

R-LinX - Wireless call button

◉ Links simply to the **R-LinX** Ah hoc Wi-Fi
◉ Buttons arrive preconfigured to connect to the R-LinX
◉ Available in any colour, as long as it's white.

PUSH - The smart little Wi-Fi button

Three stage Escalation ◉
60ft (Dependant upon the infrastructure) ◉
LED: Status Ring Indicator (White, Red, Green) ◉
Three Push Triggers: Short, Double and Long Press ◉
Batteries: 3x AAA (Included) ◉
Batteries life: 12 months (Based on 10 presses a day) ◉
Mount: Screw, Glue/Magnetic ◉
Dimensions: 60mm x 60mm x 32mm ◉

CONNECT - Simply to the **R-LinX**

Links to radios via a tethered Hytera MD785 with UART
conversion, directly via the IP Hytera repeater, conventional
mode only, or tethered Motorola DMR Control Radio.

◉ RS232 or RS485 Serial Ports
◉ 4x USB 2.0 Ports
◉ 4x Onboard Contact Closures (Easily expandable to 12 via a
◉ Brainbox ED-588 GPIO module)
◉ TCP and IP Client In/Out
◉ Power Consumption: +5V DC, 2.6 Amps
◉ SMS -Separate USB GSM D-Link Dongle and
  SIM Card Required
◉ Dimensions: 120mm x 110mm x 23mm

ALERTS - Sent to Hytera or Motorola radios

Notifications via SMS and email, plus activate sirens/sounders.* ◉
*Network/LAN connection or additional hardware required ◉

AIRSYS

R-LinX
WiFi Button

FEATURES

- ◉ Connect and go, with the straightforward alarm monitoring module.
- ◉ Simple to set-up and configure, with built in test and discovery tools.
- ◉ Integrates with **R-LinX** Wi-Fi Buttons
- ◉ Integrates with emergency alarms, access systems and machinery.
- ◉ Notifications to DMR Radios, Radio Group, SMS, email.
- ◉ Escalation three stage alert
- ◉ Serial Input Sentence Message Parsing with Keyword and Omit word functionality.
- ◉ TCP Input Sentence Message Parsing with Keyword and Omit word functionality.
- ◉ Radio Keyword In to start the alert escalation.
- ◉ Radio or SMS Keyword In to activate onboard contact closure outputs.
- ◉ Lone Worker for up to ten users, with event log.
- ◉ Alert logging as a CSV file.
- ◉ No Licence or support fees.

INSTALL

Unpack, screw in, stick or place anywhere you like | Launch the **R-LinX** application on your PC | Set-up your short, double and long press messages

Easy to check: Plug in the **R-LinX** and tether a radio in the preferred location.
Go to the ideal button location and press, if the ring goes green your good to go.

Environment: Only suitable for indoor use – keep away from humidity

023 8071 8700
sales.uki@airsys.com
www.airsys.co.uk

AIRSYS